

# Office Green Points List September 2010

## ■ Toner & Inkjet Cartridges

Office Green ■ 08700 50 20 50 ■ www.officegreen.co.uk ■ info@officegreen.co.uk ■  
Keep legal, keep green with Office Green



### How to use this list

To qualify for a free collection of your used toner & inkjet printer cartridges and mobile phones please ensure that you have at least 10 that appear on our most current points lists - monthly lists are available on the homepage of our website [www.officegreen.co.uk](http://www.officegreen.co.uk). Please also include toner & inkjet printer cartridges and mobile phones that are not listed in addition to the minimum criteria.

*\*\*NB: Toner bottles, toner kits and ribbons are not accepted - in excess of 10% of these items in any one collection will result in a zero collection value.\*\**

**To arrange a collection of your items call us on 08700 50 20 50**

### Terms & Conditions

- You must have a minimum of 10 items from this points list to qualify\* for a free collection.
- Items must be undamaged and mobile phones must also include their battery.
  
- Prices shown are based on current market value, are subject to market fluctuations, and therefore should be used as a guide only.
- **Office Green is unable to make a payment for any consignment that contains less than 10 items from the lists current at the time of collection, or in excess of 10% waste items (toner kits, toner bottles, ribbons or any other miscellaneous items received.**
- Collectors who cannot meet the minimum requirement or have a collection profile which Office Green deem does not qualify\* for a free collection, can opt to pay a minimum charge of £25 for up to 20 kilos plus 50 pence per subsequent kilo to have their toner cartridges, inkjet cartridges and mobile phones collected and recycled.
- For latest terms & conditions please see our website [www.officegreen.co.uk](http://www.officegreen.co.uk).
- If you have large quantities of unused items please email a list to [info@officegreen.co.uk](mailto:info@officegreen.co.uk) for a quotation.
- **PLEASE NOTE : ALL POINTS CLAIMS MUST BE SUBMITTED WITHIN SIX MONTHS OF TRANSACTION DATE (AS PER DATE SHOWN ON POINTS CONFIRMATION FORM).**

### All listed Toner Cartridges now 0.75 points each (original spec only)

Manufacturer	Product Reference	Printer Model
Brother	DR2000	HL 2030/2040
Brother	DR2100	HL 2140/2150/2170
Brother	DR2005	HL 2035/2045
Brother	DR3000	HL 5100
Brother	DR3100	HL 5240/5250
Brother	DR3200	HL 5340/5350
Brother	DR6000	HL 1200 Series
Brother	TN130/135	HL 4050CN Black/Colour
Brother	TN230	HL 3040CN/3070CW Black/Colour
Brother	TN2000	HL 2030 (No Starter Cartridge)
Brother	TN2005	HL 2035/2045
Brother	TN2110	HL 2140/2150/2170
Brother	TN2120	HL 2140/2150/2170
Brother	TN3130/3170	HL 5200 Series ( <b>must include cover</b> )
Brother	TN3230/3280	HL 5340/5350
Brother	TN6300/6600	HL 1200 Series
Canon	E16/E30 (made in Japan)	FC310/FC330 Copier
Canon	E16/E30 (not made in Japan)	FC310/FC330 Copier
Canon	EP-27	LBP 3200Series

Manufacturer	Product Reference	Printer Model
Canon	EP-52	LBP-1760/1760e
Canon	EP-62	LBP-1610/1810/910
Canon	EP-72	LBP-1910/3260
Canon	EP-W	LBP-2460
Canon	FX10	L-100/120Fax
Canon	Cart 103/303/703	LBP-100/2900/3000/100/Fax L120
Canon	Cart 108/308/50//708	LBP-3300/3360
Canon	Cart 108ii/308ii/501ii/708ii	LBP-3300/3360
Canon	Cart 310/510/710	LBP-3410/3460
Canon	Cart 310ii/510ii/710ii	LBP-3410/3460
Canon	Cart 312/712	LBP-300/3010
Canon	Cart 313/713	LBP-3250
Canon	Cart 509	LBP-3500/3900/3950
Canon	Cart 706 Toner	Imageclass 6500
Canon	Cart 716 Toner	LBP-5050
Canon	Cart 720 Toner	i-SENSYS MF6880DN

Dell	J9341/J9833	1100
Dell	NF555/PF028/RF012	3110/3115 Colour Toners
Dell	MV559/GR332	1720 Toner
Dell	T2727/K717J/P58*K/P75*K/M80*K	2145CN Colour Toners
	H515C/H514C/H513C	3130 Colour Toners
Dell	GD531/PD974/HD767/TD381	5210N
Dell	UD314/RD907	5310N/W5300
Dell	RF223/NF485/PF656/PF658	1815DN
Dell	PK492/PK491/PK937/DM254	2330D
Dell	NY312/313	5330D
Dell	RO136/RO137	M5200/W5300

Epson	S050166/167 toner	EPL6200
Epson	1124/1125/1126/1127	C3800 Hi-Cap Toners

Fusers	All HP Mono Fusers	Except 1160/2100/4000/5000/5100/8100
Fusers	RG5-6913-000CN	HP Colour LaserJet 2500
Fusers	RG5-7573-000CN	HP Colour LaserJet 2550
Fusers	RM1-1821-000CN	HP Colour LaserJet 2600
Fusers	RM1-2473-000CN	HP Colour LaserJet 3000
Fusers	RM1-0430-000CN	HP Colour LaserJet 3500
Fusers	RG5-6517-000CN	HP Colour LaserJet 4600
Fusers	RM1-1734-000CN	HP Colour LaserJet 4700
Fusers	RG5-6701-000CN	HP Colour LaserJet 5500
Fusers	RG5-6098-000CN	HP Colour LaserJet 9500

HP	C3909A/X	LaserJet 5Si/8000
HP	C4096A	LaserJet 2100
HP	C4127A	LaserJet 4000/4050
HP	C4127X	LaserJet 4000/4050
HP	C4129X	LaserJet 5000/5100
HP	C4182X	LaserJet 8100 Series/Mopier 320
HP	C8061A	LaserJet 4100
HP	C8061X	LaserJet 4100
HP	C8543X	LaserJet 9000
HP	CB435A	LaserJet 1120/M1522/P1505
HP	CB435A Introductory	LaserJet 1120/M1522/P1505
HP	CB436A	LaserJet 1120/M1522/P1505
HP	CB436A Introductory	LaserJet 1120/M1522/P1505
HP	CB540/1/2/3	LaserJet 1215/1515/1518
HP	CC364A	LaserJet 4014/P4015/P4515
HP	CC364A previously recycled	LaserJet 4014/P4015/P4515
HP	CC364X	LaserJet 4015/P4515
HP	CC364X previously recycled	LaserJet 4015/P4515
HP	CC530A/1A/2A/3A	LaserJet CP2025
HP	CE250A/1A/2A/3A	LaserJet CP3525/3530
HP	CE250X	LaserJet CP3525/3530
HP	CE260A/1A/2A/3A	LaserJet CP4025/4525
HP	CE260X	LaserJet CP4025/4525
HP	CE740A/1A/2A/3A	LaserJet CP5225

Manufacturer	Product Reference	Printer Model
HP	CE278A	LaserJet Pro P1606N
HP	CE285A	LaserJet Pro P1102
HP	CE255A	LaserJet P3015
HP	CE255X	LaserJet P3015
HP	CE505A	LaserJet 2055
HP	CE505X	LaserJet 2055
HP	Q1338A	LaserJet 4200
HP	Q1339A	LaserJet 4300
HP	Q2612A	LaserJet 1010/1012/1015
HP	Q5942A	LaserJet 4250/4350
HP	Q5942X	LaserJet 4250/4350
HP	Q5945A	LaserJet 4345/MF4345
HP	Q5949X	LaserJet 1320
HP	Q5951A	LaserJet 4700 Cyan
HP	Q5952A	LaserJet 4700 Magenta
HP	Q5953A	LaserJet 4700 Yellow
HP	Q6461A	LaserJet 4730 Cyan
HP	Q6462A	LaserJet 4730 Yellow
HP	Q6463A	LaserJet 4730 Magenta
HP	Q6471A	LaserJet 3600 Cyan
HP	Q6472A	LaserJet 3600 Yellow
HP	Q6473A	LaserJet 3600 Magenta
HP	Q6511A	LaserJet 2400
HP	Q6511X	LaserJet 2400
HP	Q7516A	LaserJet 5200
HP	Q7551A	LaserJet M3027/3035/P3005
HP	Q7551X	LaserJet P3005
HP	Q7553A	LaserJet P2015
HP	Q7553X	LaserJet P2015
HP	Q7570A	LaserJet M5025
HP	Q7581A	LaserJet 3800 Cyan
HP	Q7582A	LaserJet 3800 Yellow
HP	Q7583A	LaserJet 3800 Magenta

IBM	28P2491/2492	1120/1125
IBM	28P2007/2007	1130/1140
IBM	75P4302/03	1332/1352/1372
IBM	75P6958/59/60/61	1532
IBM	39V0542/0543/0544/0545	1570
IBM	39V3202/3203/3204/3206	1811/1812/1822
IBM	39V2511/2513/2514/2515	1832/1852/1872

Konica Minolta	AV03**	Magicolor 1600 Toners
Konica Minolta	1710591-001	Magicolor 2400/2500 Drum

Lexmark	0012016SE	E120
Lexmark	E250A11E	E250
Lexmark	08A0475/0476/0477/0478	E320
Lexmark	12A7300/7305/7400/7405	E321
Lexmark	12A8300/18305/8400/8405	E230/E330
Lexmark	E24016/E24036/E34016/E34036	E340/E342
Lexmark	E352H11E	E350
Lexmark	E260A11E/A21E/E360H11E/H21E	E260/E360/E460
Lexmark	E450H11E	E450
Lexmark	E460X11E/E460X21E	E460
Lexmark	1382628/1382925	Optra S
Lexmark	12A8420/8325/8425	T430
Lexmark	12A5740/5745	Optra T610/T612/T614/T616
Lexmark	12A5840/5845	Optra T610/T612/T614/T616
Lexmark	12A6730/6830/6835	T520/T522
Lexmark	12A6860/6865/6869	T620/T622
Lexmark	12A7460/7462/7465	T630/T632/T634
Lexmark	0064016HE	T640
Lexmark	64416XE/64436XE	T644
Lexmark	X644X11E/X21E/H11E/H21E	X644/X642
Lexmark	X340A11G/X340A21G	X340/X342
Lexmark	X363A11G/A21G/H11G/H21G	X363

Manufacturer	Product Reference	Printer Model
Lexmark	T650A11E/A21E/H11E/H21E/H04A	T650/T652/T654
Lexmark	T654X11A/X21A/X04A	T654
Lexmark	X651H11A/H21A/A11A/A21A/X04A	X651/X652/X654/X656/X658
OKI	44250717-0723	C110/C130n/MC160n Toner
OKI	4345929/30/31/32/33/34/35/36	C3300/C3400 Toner
Panasonic	UG-3350	Panafax UF-585/595
QMS	1710591-001	Magicolor 2400/2500 Drum
Ricoh	Type 1265	Fax 1120/1160
Ricoh	Type 1275	Fax 1130L
Ricoh	Type 1430/1435	Fax 1800L/2000L
Ricoh	Type 1260	Fax 3310L
Samsung	ML-1610	ML-1610
Samsung	ML-1630, W, SCX 4500	ML-1630
Samsung	MLT-1082S	ML-1640/ML-2240
Samsung	ML-2010	ML-2010
Samsung	ML 3050	ML 3050
Samsung	SCX-4200	SCX-4200
Samsung	SCX-4521D3	SCX-4321/4521F
Samsung	SCX 5530	SCX-5530
Xerox	106R01159	Phaser 3117
Xerox	113R711/712/715	Phaser 4510
Xerox	113R719/20/21/23/24/25	Phaser 6180
Xerox	13R00621	WorkCentre Pe220

**All listed Inkjet Cartridges now 0.35 points each (original spec only)**

Manufacturer	Model	Printer
Canon	BC-02	BJ200/230
Canon	BX-3	B100/110/150/155
Canon	CL-38	MP210/220/470
Canon	CL-41	MP450/170/150/IP2200/IP1600
Canon	CL-51	MP450/170/150/IP2200/IP1600
Canon	PG-37	MP210/220/470
Canon	PG-40	MP450/170/150/IP2200/IP1600
Canon	PG-50	MP450/170/150/IP2200/IP1600
Canon	PG-510	MP480/240/260
Canon	PG-512	MP480/240/260
Canon	CL-511	MP480/240/260
Canon	CL-513	MP480/240/260
Dell	JF333	725/810
Dell	M4640	922/924/942/946/962/964
Dell	M4646	922/924/942/946/962/964
Dell	MK990/992	926
Dell	MK991/993	926
Dell	KX701/JP451	948
Dell	KX703/JP453	948
Dell	DH828/CH883	966/968
Dell	DH829/CH884	966/968
HP	C6656A No.56	DeskJet 450cbi/555c0/5552
HP	C6657A No.57	DeskJet 450cbi/555c0/5552
HP	C6657A No.57 previously recycled	DeskJet 450cbi/555c0/5552
HP	C6657G No.57	DeskJet 450cbi/555c0/5552
HP	CB267A/CB269A No.57	DeskJet 450cbi/555c0/5552
HP	CB278A No.57+	DeskJet 450cbi/555c0/5552
HP	CB335EE No.350	OfficeJet D4260/J5780

Manufacturer	Product Reference	Printer Model
HP	CB335EE No.350 previously recycled	OfficeJet D4260/J5780
HP	CB336EE No.350 XL	OfficeJet D4260/J5780
HP	CB336EE No.350 XL previously recycled	OfficeJet D4260/J5780
HP	CB337EE No.351	OfficeJet D4260/J5780
HP	CB337EE No.351 previously recycled	OfficeJet D4260/J5780
HP	CB338EE No.351 XL	OfficeJet D4260/J5780
HP	CB338EE No.351 XL previously recycled	OfficeJet D4260/J5780
HP	C6578A/D No.78	DeskJet 930/950/970/980/990/G55/G85/G95
HP	C8727A No.27	DeskJet 3320/3325/3420/3550
HP	C8728A No.28	DeskJet 3320/3325/3420/3550
HP	C8765E No.338	DeskJet 5740/6520/6540/6840
HP	C8765E No.338 previously recycled	DeskJet 5740/6520/6540/6840
HP	C8765E No.338 intro	DeskJet 5740/6520/6540/6840
HP	C8766E No.343	DeskJet 5740/6520/6540/6840
HP	C8766E No.343 previously recycled	DeskJet 5740/6520/6540/6840
HP	C9351A No.21	DeskJet 3920/3940/1410
HP	C9351C No.21XL	DeskJet 3920/3940/1410
HP	C9352A No.22	DeskJet 3920/3940/1410
HP	C9352A No.22 previously recycled	DeskJet 3920/3940/1410
HP	C9352C No.22XL	DeskJet 3920/3940/1410
HP	CB304A No.110	Photosmart A5516/423/433
HP	CB334A No.54	DeskJet 3920/3940/1410
HP	CC640EE No.300	DeskJet F4280
HP	CC640EE No.300 previously recycled	DeskJet F4280
HP	CC641EE No.300XL	DeskJet F4280
HP	CC641EE No.300XL previously recycled	DeskJet F4280
HP	CC643EE No.300	DeskJet F4280
HP	CC643EE No.300 previously recycled	DeskJet F4280
HP	CC644EE No.300XL	DeskJet F4280
HP	CC644EE No.300XL previously recycled	DeskJet F4280
HP	C9363E No.344	DeskJet 5740/6520/6540/6840
HP	C9362E No.336	DeskJet 5400
HP	C9361E No.342	DeskJet 5400
HP	C9364E No.337	DeskJet 5940/6940/6980/D4160
HP	CC653A No.901	OfficeJet J4580/J4660/J4680
HP	CC654A No.901XL	OfficeJet J4580/J4660/J4680
HP	CC656A No.901	OfficeJet J4580/J4660/J4680

Lexmark	10N0016/217 No.16 & No.17	Jetprinter i3/Z13/Z23/Z33
Lexmark	10N0026 No.26	Jetprinter i3/Z13/Z23/Z33
Lexmark	13400HC	Jetprinter 4076
Lexmark	18C0034E No.34	Z815/X5250
Lexmark	18C0035E No.35	Z815/X5250
Lexmark	17G0050 No.50	Jetprinter Z12/22/32705
Lexmark	12A1970 No.70	Jetprinter 3200/50005700/5770
Lexmark	12A1975 No.75	Jetprinter 3200/50005700/5770
Lexmark	18C0781E No.1	X2350
Lexmark	18C0190 No.2	X2580/X3580
Lexmark	18C1530E No.3	X2580/X3580

Neopost	IJ25/IJ30/IJ65/IJ90/IJ110	IJ25/30/35/40/45/50/65/90/110
---------	---------------------------	-------------------------------

Samsung	M41	SF-370/SF-375
---------	-----	---------------

Sharp	UXC70B	UX-B700
-------	--------	---------