

Office Green Points List

Toner Cartridges, Inkjet Cartridges & Fuser Units



Step 1 - All you need is 10 listed items!

In order to qualify for a free collection, all you need to have is a minimum of 10 items from this and/or our mobile phone points list combined.....simple!

Items returned must be undamaged and original (i.e. not previously recycled), as their primary worth is for reuse not raw material recycling.

Mobile phones must include their batteries and rear covers to be 'working value', chargers and accessories are not required.

This list is updated monthly and the latest version is always available on the home page of our web site www.officegreen.co.uk

Step 2 - You can also include your unlisted and unused items, as many as you want!

Once you have this minimum listed quantity (and there is no maximum*), we will also collect free of charge any other toner cartridges, inkjet cartridges, fuser units or mobile phones that are not listed with your listed items.

We will ensure that these unlisted items are reused or recycled and not sent to landfill, thus ensuring your own duty of care compliance. Unlike most waste companies, we will make no charge for this additional recycling service.

Step 3 - Waste items – no thanks!

Please note toner bottles, toner kits, toner containers, ribbons etc are all classified as “waste” and should not be included in your collection.

If you do include more than 10% of these waste items within your collection or send less than 10 points listed products, unfortunately you will not earn any points for the entire collection.

If you are unsure or have difficulty in identifying what this waste is, please contact us for more information.

*Office Green
we keep you
legal, we keep
you green*

Step 4 - Your options if you do not qualify for a free collection

If you do not qualify for a free collection please see our website or ask for more details on our:

- Freepost returns program for small quantities of listed inkjets or mobiles
- Unique Pay As You Go, non-landfill, environmentally friendly recycling service

To book your **FREE** collection please call us on:
08700 502050 (local rate), visit www.officegreen.co.uk or
email us at collections@officegreen.co.uk

(* subject to our fair usage policy.)

Reuse the past, Recycle the present, Save the future

Reuse the past,
Recycle the present,
Save the future.



November 2017 Cartridge and Fuser Points

All listed Toner Cartridges now 0.75 points each (original unless specified otherwise).

Brother	Product Reference	Printer Model
Brother	DR320CL	HL 4140CN
Brother	DR321CL	HLL 8250CDN
Brother	DR2300	HL 23000D
Brother	DR3400	HL 6250/6400
Brother	TN1700	HL 8050
Brother	TN2000	HL 2030
Brother	TN2005	HL 2035/2045
Brother	TN2110/TN2120	HL 2140/2150/2170
Brother	TN230/TN235	HL 3040CN/3070CW BCMY
Brother	TN241/TN245	HL 3140CW BCMY
Brother	TN242/TN246	HL 3142CW BCMY
Brother	TN320/TN325	HL 4140CN BCMY
Brother	TN321/TN326	HL L8250CDN BCMY
Brother	TN3330/TN3380/TN720/TN750	HL 5440/5450/5470
Brother	TN3430/TN3480	HL 6250/6400
Brother	TN3512/TN3500	HL 6250/6400 High Cap
Brother	TN6300/TN6600	HL 1200/1400 Series
Canon	Product Reference	Printer Model
Canon	CRG-310ii/510ii/710ii	LBP-3410/3460
Canon	CRG-527	LBP-8610
Canon	CRG-323/723	LBP-7750C BCMY
Canon	CRG-732	LBP-7780 BCMY
Canon	CRG-719/719H	LBP-6300/6650 MF5840
Canon	CRG-322/322II	LBP-9100C/9500C/9600C BCMY
Canon	C-EXV28 Drum	iRC5045/C5051 Drum
Canon	C-EXV29 Drum	iRC5030 Drum
Canon	C-EXV37 Drum	iR-1730i/1740i/1750i
Canon	C-EXV34 Toner	iR-C2020/2025/2030 CMY Only
Canon	C-EXV47	iR C250/C250i/C350i Toner and Drum
Canon	C-EXV49	iR-C3325/3325i/3330 Toner and Drum
Dell	Product Reference	Printer Model
Dell	DRYXV/G9W85	B126X
Dell	PK492/PK941/PK937/DM254	2330 Toner
Dell	UD314/RD907/HD767/TD381/GD531/PD974	5210N/5310N
Dell	D524T/F362T/2KMVD/F361T/Y902R/YPMDR	5230/5320/5350
Epson	Product Reference	Printer Model
Epson	SO51228	AL-M300/AL-MX300 Photoconductor
Epson	S051111	EPL-N3000
Epson	S051073	EPL-N4000
Epson	S051170	M4000

we keep you legal, we keep you green

Reuse the past,
Recycle the present,
Save the future.



HP	Product Reference	Printer Model
HP	Q5950A/51A/52A/53A 643A	Colour LaserJet 4700
HP	Q6460A/61A/62A/63A 644A	Colour LaserJet 4730
HP	C9730/31/32/33A 645A	Colour LaserJet 5500
HP	CF031A/032A/CF033A 646A	Colour LaserJet CM4540
HP	CE310A/11A/12A/13A 126A	Colour LaserJet CP1025 (no starters)
HP	CE250X 504X	Colour LaserJet CP3525
HP	CE250A/51A/52A/53A 504A	Colour LaserJet CP3525
HP	CB400A/01A/02A/03A 642A	Colour LaserJet CP4005
HP	CE260X 648X	Colour LaserJet CP4025/4525
HP	CE260A/61A/62A/63A 648A	Colour LaserJet CP4025/4525
HP	CE740A/41A/42A/43A 307A	Colour LaserJet CP5225
HP	CE270A/71A/72A/73A 650A	Colour LaserJet CP5520
HP	CF350A/51A/52A/53A 130A	Colour LaserJet M176 (no starters)
HP	CF400X/01X/02X/03X 201X	Colour LaserJet M252 Hi-Cap
HP	CF410A/11A/12A/13A 410A	Colour LaserJet M452
HP	CF410X/11X/12X/13X 410X	Colour LaserJet M452 Hi-Cap
HP	CE400X 507X	Colour LaserJet M551
HP	CE400A/01A/02A/03A 507A	Colour LaserJet M551
HP	CF360X/61X/62X/63X 508X	Colour LaserJet M552 Hi-Cap
HP	CF330X 654X	Colour LaserJet M651
HP	CF331/32A/33A 654A	Colour LaserJet M651
HP	CF450A/51A/52A/53A 655A	Colour LaserJet M652/653/681/682
HP	CF460X/61X/62X/63X 656X	Colour LaserJet M652/653 Hi-Cap
HP	CF320X 653X	Colour LaserJet M680
HP	CF321A/22A/23A 653A	Colour LaserJet M680 CMY Only
HP	CF470X/71X/72X/73X 657X	Colour LaserJet M681/682 Hi-Cap
HP	CE341A/42A/343A 651A	Colour LaserJet M775 CMY Only
HP	CE505A 05A	LaserJet 2055
HP	CE505X 05X	LaserJet P2035/P2055
HP	CC364X 64X	LaserJet 4015/4515
HP	C8061X	LaserJet 4100
HP	Q1338A 38A	LaserJet 4200
HP	Q5942A 42A	LaserJet 4250/4350
HP	Q5942X 42X	LaserJet 4240/4250/4350
HP	Q1339A 39A	LaserJet 4300
HP	Q5945A 45A	LaserJet 4345/MF4345
HP	Q6511X 11X	LaserJet 2400/10/20/30
HP	CE390X 90X	LaserJet M4555
HP	Q7570A 70A	LaserJet M5025
HP	CF287A 87A	LaserJet M506/520
HP	CF287X 87X	LaserJet M506/520
HP	CF237A 37A	LaserJet M607
HP	CF237X 37X	LaserJet M607/M608
HP	CF237Y 37Y	LaserJet M607/M608
HP	CF281A 81A	LaserJet M630mfp
HP	CF281X 81X	LaserJet M630mfp
HP	CF230A 30A	LaserJet Pro M203/227
HP	CF230X 30X	LaserJet Pro M203/227
HP	CF217A 17A	LaserJet Pro M102/104/130/132

we keep you legal, we keep you green

Reuse the past,
Recycle the present,
Save the future.



HP (continued)	Product Reference	Printer Model
HP	CF219A 19A	LaserJet Pro M102/104/130/132
HP	CF226A 26A	LaserJet Pro M402/426
HP	CF226X 26X	LaserJet Pro M402/426
HP	CF228A 28A	LaserJet Pro M403
HP	CF228X 28X	LaserJet Pro M403
HP	CF256A 56A	LaserJet Pro M436N
HP	CF256X 56X	LaserJet Pro M436N

HP Fuser	Product Reference	Printer Model
HP Fuser	RM1-2764-000CN	Colour LaserJet 3800
HP Fuser	RM1-1734-000CN	Colour LaserJet 4700
HP Fuser	RM1-3146-000CN	Colour LaserJet 4730
HP Fuser	RG5-6701-000CN	Colour LaserJet 5500
HP Fuser	RM1-4995-000CN	Colour LaserJet CP3525
HP Fuser	RM1-5606-000CN	Colour LaserJet CP4525
HP Fuser	RM1-6095-000CN	Colour LaserJet CP5225
HP Fuser	RM1-6082-000CN	Colour LaserJet CP5520/CP5525
HP Fuser	RM1-9373-000CN	Colour LaserJet M775
HP Fuser	RM2-5028-000CN	Colour LaserJet M880
HP Fuser	RM1-1083-000CN	LaserJet 4250
HP Fuser	RG5-5751-000CN	LaserJet 9000
HP Fuser	RM1-8936-000CN	LaserJet M600
HP Fuser	RM2-6342-000CN	LaserJet M604/605/606
HP Fuser	RM1-7397-000CN	LaserJet M4555
HP Fuser	RM2-5013-000CN	LaserJet M800
HP Fuser	RM1-9814-000CN	LaserJet M806/830
HP Fuser	RM1-4579-000CN	LaserJet P4014/P4015

IBM	Product Reference	Printer Model
IBM	39V3202/3203/3204	Infoprint 1811
IBM	39V0542/543/544/545	Infoprint 1570
IBM	39V2511/513/514/515	Infoprint 1832/1852/1872
IBM	39V3713/715/715/717	Infoprint 1930/1940

Kyocera	Product Reference	Printer Model
Kyocera	TK560 KCMY	C5300N
Kyocera	TK150 KCMY	C1020
Kyocera	TK160	FS-1120
Kyocera	TK170	FS-1320D
Kyocera	TK5140 KCMY	M6030CDN
Kyocera	TK5150 KCMY	M6035CDN
Kyocera	TK5160 KCMY	P7040CDN
Kyocera	TK1140	FS-1035MFP
Kyocera	TK1130	FS-1130MFP

Lexmark	Product Reference	Printer Model
Lexmark	C540/C544/X544	C540/C544/X544 BCMY
Lexmark	C930H2*G	C930/935 BCMY
Lexmark	700**/702**	CS310/410/510 BCMY
Lexmark	74C****	CS720/725 BCMY

we keep you legal, we keep you green

Reuse the past,
Recycle the present,
Save the future.



Lexmark (continued)	Product Reference	Printer Model
Lexmark	72K****	CS820/860 BCMY
Lexmark	84C****	CX720/725 BCMY
Lexmark	82K****	CX820/860 BCMY
Lexmark	800**/802**	CX310/CX410/CX510 BCMY
Lexmark	X945X2*G	X940/945 BCMY
Lexmark	500UA/502* Toner	MS310/510/610
Lexmark	620XA/622* Toner	MS710/810
Lexmark	500UA/502* Toner	MX310/410/610/611
Lexmark	620XA/622* Toner	MX711/811/812
Lexmark	64016HE/SE 64036HE/SE	T640/642/644 Standard and High Yield
Lexmark	650A11E/T650A21E	T650/652/654/656 Standard Yield
Lexmark	650H11E/T650H21E	T650/652/654/656 High Yield
Lexmark	654X11A/T654X21A	T654/656 Extra High Yield
Lexmark	E250A11E/E250A21E	E250 Toner
Lexmark	E260A11E/E260A21E	E260 Toner
Lexmark	E352H11E/E352H21E	E350/352 Toner
Lexmark	E360H11E/E360H21E	E360 Toner
Lexmark	E450A11E/A21E/H11E/H21E	E450 Toner
Lexmark	E460X11E/E460X21E	E460 Toner
Lexmark	X363A11G/X363A21G	X363 Toner
Lexmark	X463H11G/X463H21G	X463 Toner
Lexmark	X644X11E/X21E/H11E/H21E	X644/X642
Lexmark	X651A11E/X651A21E	X651/652/654/656/658 Standard Yield
Lexmark	X651H11E/X651H21E	X651/652/654/656/658 High Yield
Lexmark	X654X11E/X654X21E	X654/656/658 Extra High Yield

OKI	Product Reference	Printer Model
OKI	09004078/79	B6200/B6300
OKI	09004447/4391	B2500/B2520/B2540
OKI	09004461/62	B6500
OKI	0129001	B710

Ricoh	Product Reference	Printer Model
Ricoh	40605*	SPC220 BCMY
Ricoh	407543/44/45/46	SPC240/250 BCMY
Ricoh	406479/80/81/82	SPC310E BCMY
Ricoh	430351	Type 1260
Ricoh	400943	P400/AP410/Type 220
Ricoh	407166	SP100E/SP112
Ricoh	413196	SP1000
Ricoh	406515/406523	SP3400/SP3500
Ricoh	400760	SP4100/4100L
Ricoh	407318	SP4510
Ricoh	841877	SP4520
Ricoh	402877	SP5200
Ricoh	407507/407510/407511	SP6430
Ricoh	407340/407323/4007318	SP3600/SP4510

Samsung	Product Reference	Printer Model
Samsung	CLT-R406	CLP-360/365 Drum

we keep you legal, we keep you green

Reuse the past,
Recycle the present,
Save the future.



Samsung (continued)	Product Reference	Printer Model
Samsung	CLT-R407	CLP-310 Drum
Samsung	CLT-R409	CLP-320 Drum
Samsung	CLT-*504 (no starters)	CLP-410/415 Colour Toners
Samsung	CLT-K506 Hi Cap Black Toner	CLP-680 Hi-Cap Black Only
Samsung	MLT-D103L/S (no starters)	ML-2950
Samsung	MLT-R116	SL-M2675 Drum
Samsung	MLT-D203/U	SL-M3320 Hi-Cap
Samsung	MLT-D204S/L	SL-M3325
Samsung	MLT-R204S/L	SL-M3325 Drum
Samsung	MLT-R304	SL-M4530 Toner
Samsung	MLT-D305*	ML-3750 Toner
Samsung	SCX-5530	SCX-5530
Samsung	SCX-6555	SCX-6555 Drum
Samsung	SCX-8030/8040	MLT-D606/607S

Xerox	Product Reference	Printer Model
Xerox	113R184	Docuprint N32/N40
Xerox	106R02773/03048	Phaser 3020 WorkCentre 3025
Xerox	106R02775/02777/02778	Phaser 3052/3260 WorkCentre 3215
Xerox	106R01378	Phaser 3100 MFP
Xerox	106R03620/22/24	Phaser 3330//3345/Work Centre 3345
Xerox	106R02720/22/31	Phaser 3610
Xerox	113R656	Phaser 4500
Xerox	113R711/712/715	Phaser 4510
Xerox	106R02744/02645/02646/02647	WorkCentre 6655
Xerox	106R03620/22/24	WorkCentre 3655

All listed Inkjet Cartridges now 0.35 points each (original unless specified otherwise).

Canon	Product Reference	Printer Model
Canon	BX3	B100/110/150 Fax
Canon	CL-38	PIXMA iP1800/2500 Colour
Canon	CL-41	PIXMA iP1600 Colour
Canon	PG-510	MP480/240/260 Black
Canon	CL-511	MP480/240/260 Colour
Canon	PG-512	MP480/240/260 Hi-Cap Black
Canon	CL-513	MP480/240/260 Hi-Cap Colour
Canon	PG-540	MG3150 Black
Canon	CL-541	MG3150 Colour
Canon	PG-540XL	MG3150 Hi-Cap Black
Canon	CL-541XL	MG3150 Hi-Cap Colour
Canon	PG-545	MG2550/MG2450/iP2850 Black
Canon	CL-546	MG2550/MG2450/iP2850 Colour
Canon	PG-545XL	MG2550/MG2450/iP2850 Hi-Cap Black
Canon	CL-546XL	MG2550/MG2450/iP2850 Hi-Cap Colour

Dell	Product Reference	Printer Model
Dell	UK852 / WP322 Series 15	V105 Black and Colour

we keep you legal, we keep you green

Reuse the past,
Recycle the present,
Save the future.



HP	Product Reference	Printer Model
HP	6615A/D No. 15	DeskJet 810/840/843
HP	C9351A No. 21	DeskJet 3920/3940/1410 Black
HP	C9351C No. 21XL	DeskJet 3920/3940/1410 Hi Cap Black
HP	C9352A No. 22	DeskJet 3920/3940/1410 Colour
HP	C9352C No. 22XL	DeskJet 3920/3940/1410 Hi Cap Colour
HP	51626A No. 26	DeskJet 500/520/540
HP	C8728A No. 28	DeskJet 3320/3325/3420/3550 Colour
HP	51640A No. 40	DeskJet 1200C Black
HP	51645A No. 45	DeskJet 970/980/990
HP	C6128A	Non Fluorescent Red
HP	C6170A	Spot Colour Blue
HP	C6195A	Fast Dry Black
HP	C8842A	Versatile Black
HP	CG400A	Non Fluorescent Red
HP	CG401A	Blue Pigment
HP	Q2344A	Black Dye 1918
HP	C6657A No. 57	DeskJet 420ci/cbi/5150/5550c/5552
HP	C6658A No. 58	DeskJet 420ci/cbi/5150/5550c/5552 Photo
HP	C9359A No. 59	DeskJet 420ci/cbi/5150/5550c/5552 Grey
HP	C2P04A No. 62 (No Instant Ink)	Envy 5640/5740/7640 Black
HP	C2P05A No. 62XL (No Instant Ink)	Envy 5640/5740/7640 Hi Cap Black
HP	C2P06A No. 62 (No Instant Ink)	Envy 5640/5740/7640 Colour
HP	C2P07A No. 62XL (No Instant Ink)	Envy 5640/5740/7640 Hi Cap Colour
HP	C9390/C9449/C9450-59A No. 70	DesignJet Z2100/Z3100
HP	C9371-74A/C9403A No. 72	DesignJet 1610/1620/1770/1790
HP	C6578/A/D No. 78 CB277A No. 77	DeskJet 930/950/970/980/990/G55/G85/G95
HP	C5061A/63A/65A No. 90	DesignJet 4000/4020/4500 CMY (400ml) Only
HP	C9464-71A No. 91	DesignJet Z6100 BCMY
HP	CC640EE No. 300	DeskJet F4280 Black
HP	CC641EE No. 300XL	DeskJet F4280 Hi Cap Black
HP	CC643EE No. 300	DeskJet F4280 Colour
HP	CC644EE No. 300XL	DeskJet F4280 Hi Cap Colour
HP	CC644EE No. 300XL	DeskJet F4280 High Colour
HP	CH561EE No. 301 (No Instant Ink)	DeskJet 1050/2050 Black New Gen
HP	CH562EE No. 301 (No Instant Ink)	DeskJet 1050/2050 Colour New Gen
HP	CH563EE No. 301XL (No Instant Ink)	DeskJet 1050/2050 Hi Cap Black New Gen
HP	CH564EE No. 301XL (No Instant Ink)	DeskJet 1050/2050 Hi Cap Colour New Gen
HP	FU66AE No. 302 (No Instant Ink)	DeskJet 2130 OJ 3830/4650 Black
HP	FU65AE No. 302 (No Instant Ink)	DeskJet 2130 OJ 3830/4650 Colour
HP	FU68AE No. 302XL (No Instant Ink)	DeskJet 2130 OJ 3830/4650 Hi Cap Black
HP	FU67AE No. 302XL (No Instant Ink)	DeskJet 2130 OJ 3830/4650 Hi Cap Colour
HP	N9K06AE No. 304 (No Instant Ink)	DeskJet 2632/3720/3732 Black
HP	N9K05AE No. 304 (No Instant Ink)	DeskJet 2632/3720/3732 Colour
HP	N9K08AE No. 304XL (No Instant Ink)	DeskJet 2632/3720/3732 Hi Cap Black
HP	N9K07AE No. 304XL (No Instant Ink)	DeskJet 2632/3720/3732 Hi Cap Colour
HP	CB338EE No. 351XL	DeskJet 4260/J5780 Hi Cap Colour
HP	CZ101A No. 650	DeskJet 2510 Black
HP	CZ102A No. 650	DeskJet 2510 Colour
HP	F6V25AE No. 652	DeskJet 1115/2135/3635/3835/4535 Black
HP	F6V24AE No. 652	DeskJet 1115/2135/3635/3835/4535 Colour

we keep you legal, we keep you green

Reuse the past,
Recycle the present,
Save the future.



HP (continued)	Product Reference	Printer Model
HP	CC656A No. 901	OfficeJet J4580/J4660/J4680 Colour
HP	CC654A No. 901XL	OfficeJet J4580/J4660/J4680 Black
HP	LOS07AE No. 973X	PageWide Pro 477DW Hi Cap
Lexmark	Product Reference	Printer Model
Lexmark	LEX18C0781E No. 1	X2350 Black
Lexmark	LEX18C0190E No. 2	X2580/3580/Z1380 Colour
Lexmark	LEX18C1530E No. 3	X2580/3580/Z1380 Black
Lexmark	LEX18C0034E No. 34	Jetprinter Z815/X5250/5270 Black
Lexmark	LEX18C0035 No. 35	JetPrinter Z815/X5250/5270 Colour
Neopost	Product Reference	Printer Model
Neopost	IJ25	IJ25
Neopost	IJ35/40/45/50/65/75/85	IS350/420/480
Samsung	Product Reference	Printer Model
Samsung	M40	SF330/335
Samsung	M41	SF370

we keep you legal, we keep you green